



SECO SIGN

GmbH

manufacturing **LAB**

Manufaktur für Kunststoffspiegel . Möbeldesign

Montage Z-Profil / mounting instruction for z-profile:

- Das untere Z-Profil gerade anlegen und möglichst weit außen an 2 Stellen durch das Profil durch in die Wand bohren (6er Bohrer). Die Dübel einsetzen und das Z-Profil mit den Schrauben festschrauben.

Achtung: Ist die Wandbeschaffenheit porös oder hohl o.ä., kann es notwendig sein spezielle Dübel zu besorgen.

- Stellen Sie den Spiegel in das Profil und wiederholen Sie den Ablauf aus Schritt 1 mit dem oberen Profil.

Achtung: Lassen Sie hier etwas Luft von 1-3mm zwischen Spiegel und Profil, um den Spiegel nicht unter Spannung zu setzen, da sich dieser sonst verziehen und die Folie Wellen schlagen kann!

- Put the lower Z-Profile horizontally on the wall and drill through the profile and through the wall (6 mm drill) two spots. The two spots should be a long way away from each other. Set the dowels into the drill holes and screw the Z-profile on the wall.

Attention: You may need special dowels if the wall is blowy or hollow.

- Set the mirror into the Z-profile and repeat the procedure with the upper profile (step 1).

Attention: In order to not set the mirror under the pressure, leave a little bit space (1-3 mm) between mirror and profile. Otherwise the frame could go out of shape and waves might appear on the surface.



Important Information – How to treat the POLLOPAS mirror

Our POLLOPAS mirror is a 100% handmade product and every step is being inspected by our production staff. Since 1975 we have been delivering our mirrors to the satisfied costumers all over the world.

In order to achieve and guarantee not only a light weighted but also durable product, we are using exclusively high-quality materials.

However, the POLLOPAS mirror is a delicate and sensitive product. Therefore, we want to give you some information how to handle it and care for it:

- The mirror foil is not pressure-sensitive however it is scratch-sensitive. Please use therefore the enclosed gloves, when you touch the mirror.
- The frame very stable. However if the frame falls on the edge, it may go out of shape and thus the foil may get wavy.
- The Pollopas foil mirror doesn't attract dust, so that it doesn't have to be cleaned very often.

Always before cleaning:

Blow off dust first (You may also use a dryer blowing a cold air).

Cleaning:

- Wipe the mirror only with a microfiber (lint-free) cloth.
- Please use water with a drop of washing-up liquid to remove fingerprints.
- We recommend special foam cleaner to remove stubborn stains.

We offer:

- Vileda microfiber cloth (3€)
- FoamCleaner (16€)

For further questions please don't hesitate to contact us.

Your SECO SIGN Team